

club phase 音響機材リスト-soundsystem list- 2020.1

Main System

Main Mixer	DiGiCo	SD8 ※ステージ上手袖にステージラック配置	Input MAX 41ch / MoniOut MAX 20ch	ver 10.5.1090
Sub Mixer	YAMAHA	MG10XU		
Effect	YAMAHA	SPX990	x2	
	Lexicon	PCM 80	x1	
	Roland	SDE 3000	x1	
Play	TASCAM	CD-500B	x2	
Line Rec	TASCAM	CD-RW900mkII	x1	
Distribution Mixer	ART	MX225	x1	
Compressor	AMEK	System9098CL	x1	
Main SP Prozessor	NEXO	NX241	x2	
Main SP P.amp	AMCRON	MA 3600VZ	x4	
Main SP	NEXO	AlphaE-M	x4	
		AlphaE-B1-18	x4	
		Alpha-S2	x2	
Infill SP P.amp	YAMAHA	PC 5500	x1	
Infill SP	Electro-Voice	ZLX-12	x2	
Monitor SP P.amp	YAMAHA	PC5500	x4	
Side fill SP	JBL	SRX715	x2	with SP Stand
Wedge SP	Electro-Voice	FMX 1502	x7	

Microphone

SHURE	SM58	x9		
	SM58sw	x4	PA BOOTH x1 常設	
	SM57	x6		
	BETA 58A	x4		
	BETA 57A	x4		
	BETA52A	x2		
	BETA91A	x1		
	SENNHEISER	e604	x3	
		e904	x5	
		e901	x1	
MD421 mk2		x2		
AKG	D-112	x1		
	C-391	x5		
Electro-Voice	N/D 468	x3		
	PL24	x1		
audio-technica	ATM25	x1		

D.I.

Radial	Pro D2	x4	2ch
COUNTRYMAN	Type-10	x2	
BOSS	DI-1	x3	

Multi Cable System

CANARE	32ch	ステージ後方-下手袖-上手袖-PAブース	貫通
	16ch	ステージ後方-上手袖-PAブース	貫通

Option

SHURE	Wireless System BLX BETA58/BLX4R	x4	B帯	※1波/¥4000
-------	----------------------------------	----	----	-----------