

club phase 音響機材リスト-soundsystem list- 2022.1

Main System						
Main Mixer	DiGiCo	SD8 ※ステージ上手袖にステージラック配置		Input MAX 41ch / MoniOut MAX 20ch	ver 12.2.1280	
Sub Mixer	YAMAHA	MG10XU				
Effect	YAMAHA	SPX990	x2			
	Lexicon	PCM 80	x1			
	Roland	SDE 3000	x1			
Play	TASCAM	CD-500B	x2			
Line Rec	TASCAM	CD-RW900mkII	x1			
Distribution Mixer	ART	MX225	x1			
Compressor	AMEK	System9098CL	x1			
Main SP Prossesor	NEXO	NX241	x2			
Main SP P.amp	AMCRON	MA 3600VZ	x4			
Main SP	NEXO	AlphaE-M	x4			
		AlphaE-B1-18	x4			
		Alpha-S2	x2			
Infill SP P.amp	YAMAHA	PC 5500	x1			
Infill SP	Electro-Voice	ZLX-12	x2			
Monitor SP P.amp	YAMAHA	PC5500	x4			
Side fill SP	JBL	SRX715	x2	with SP Stand		
Wedge SP	Electro-Voice	FMX 1502	X7			
Microphone						
	SHURE	SM58	x9			
		SM58sw	x4		PA BOOTH x1 常設	
		SM57	x6			
		BETA 58A	x4			
		BETA 57A	x4			
		BETA52A	x2			
		BETA91A	x1			
		SENNHEISER	e604	x3		
			e904	x5		
			e901	x1		
		MD421 mk2	x2			
	AKG	D-112	x1			
		C-391	x5			
	Electro-Voice	N/D 468	x3			
		PL24	x1			
	audio-technica	ATM25	x1			
D.I.						
	Radial	Pro D2	x4	2ch		
	COUNTRYMAN	Type-10	x2			
	BOSS	DI-1	x3			
Multi Cable System						
	CANARE	32ch		ステージ後方-下手袖-上手袖-PAブース	貫通	
		16ch		ステージ後方-上手袖-PAブース	貫通	
Option						
	SHURE	Wireless System BLX BETA58/BLX4R	x4	B帯	※1波/¥4000	